

SK

Prevleko položite na likalno desko, konce vrvice potegnite nekaj centimetrov iz obrobe.

Oba konca vrvice potegnite navzdol, tako da prevleka objema okrogli del likalne deske.

Vrvice nategnite, dokler se prevleka ne oprime robov likalne deske.

Art: C 34, C42, C48, C34F3, C42F3, C48F3



Art: DC 34 DC 42, DC 48, DC 34F3, DC 42F3, DC48F3, DC34 F3M, DC 42F3M, DC48F3M, DC34F3R, DC42F3R, DC48F3R

