

## SR

Postaviti navlaku na dasku za peglanje, povući trakice na krajevima dok ne izađu krajevi kanapa koji idu uz rub navlake.

Namestiti navlaku tako da prekrije ivice daske za peglanje.

Zategnuti kanap do kraja kako bi navlaka nalegla preko daske za peglanje.

Art: C 34, C42, C48, C34F3, C42F3, C48F3



Art: DC 34 DC 42, DC 48, DC 34F3, DC 42F3, DC48F3, DC34 F3M, DC 42F3M, DC48F3M, DC34F3R, DC42F3R, DC48F3R

